8 Wiring Diagram

_	2	3	4	5	9	7	8	6	
BL_PWM	GND	GND	GND	13V	13V	13V	BL_ANALOG	BL_EN	

8 6 10 7 12 13 15 16 17 20 21 22 23 24 24 26 26 30 29 27 3 2 9 6 TXBC+
GND
TXB3TXB3+
GND
NC GND TXB1-TXB1+ GND TXB2+ GND TXBC-TXB0-TAC-TXB2-TA2-TA2+ GND 5V TA0-TA3+ TA1+ TA3-

CN700 Connected to the I/P board CN701
Connected to the Panel through the LVDS cable

NC	1
RXD	2
TXD	3
NC	4
GND	5
GND	6
GND	7
GND	8

CN300

For test(not used)

MAIN BOARD

CN210 For DVI signal

NC	5V	CHK_DVI	5V	RC0-	RX0+	GND	OZ	OZ	GND	RXC+	RXC-
13	14	15	16	17	18	19	20	21	22	23	24
RX2-	RX2+	GND	NC	NO	SCL	SDA	ON	-IXXI	RX1+	GND	NC
_	2	က	4	5	9	7	80	6	10	11	12

	For Analog signal								al	CI	V 1	01		
RED	GREEN	BLUE	GND	GND	GND	GND	GND	5V	GND	GND	SDA	HSYNC	VSYNC	SCA
_	2	3	4	5	9	7	80	6	10	7	12	13	14	15

For function key CN702

GND	3,3V	Power_Key	LED_Green	Key2	Key1	GND	
1	2	3	4	5	9	7	

8 Wiring Diagram

Memo